

Kompatibilnost pogona i upravljača

Pregled mogućnosti kombinovanja pogona ili prijemnika sa odašiljačima ili kontrolama

PLASTEAL
tech

selve

ODAŠILJAČI/UPRAVLJAČI

		SELVE Home Server 2	commeo bežični sistem														Žična veza		
			commeo bežični sistem										iveo bežični sistem				Žična veza		
			Multi Send	Wall Send	Send 1/10	Send 1 Basic	Light Send	Sensor WS	Timer BT	Control	Receive	Receive Connect	Multi Send	Send 1/10	Wall Send	I-R Sensor svetla	Selvetajmer Plus	Smartajmer Plus	Zidni prekidač
POGONI	SE Pro								X	X	X	X					X	X	X
	SE Pro-RC	X	X	X	X	X	X	X	X				X	X	X	X	(X)	(X)	X
	SE Solar-com	X	X	X	X	X	X	X	X										
	SEE								X	X	X	X					X	X	X
	SEE-RC	X	X	X	X	X	X	X	X				X	X	X	X	(X)	(X)	X
	SEE-NHK								X	X	X	X					X	X	X
	SE Plus								X	X	X	X					X	X	X
	SE Plus-RC	X	X	X	X	X	X	X	X				X	X	X	X	(X)	(X)	X
	SEZ								X	X	X	X					X	X	X
	SEZ-RC	X	X	X	X	X	(X)	X	X				X	X	X	(X)	(X)	(X)	X
	SEZ-NHK								X	X	X	X					X	X	X
	SE Breeze-com	X	X	X	X	X	(X)	X	X								(X)	(X)	X
	SEM Plus								X	X	X	X					X	X	X
	SEM Plus-RC	X	X	X	X	X	(X)	X	X				X	X	X	(X)	(X)	(X)	X
	SP								X	X	X	X					X	X	X
	SP Rescue								X	X	X	X					X	X	X
	SP-NHK								X	X	X	X					X	X	X
PRIJEMNICI	commeo Timer BT	X	X	X	X	X	X	X	(X)	(X)									
	commeo Control	X	X	X	X	X	X	X	X	(X)									
	commeo Receive	X	X	X	X	X	X	X	X				X	X	X	X	X	X	X
	commeo Receive Connect	X	X	X	X	X	X	X	X				X	X	X	X	(X)	(X)	
	commeo Adapter Plug	X	X	X	X	X	(X)		X				X	X	X				

(X) = tehnički izvodljivo, ali nije uobičajena praksa

